

Ch. Barnes
Perkins Engines Co. Ltd
Peterborough
England

7

The Sensitivity and Repeatability of Nanoparticle Measurements at High Dilution Ratios

3rd International ETH Workshop on Nanoparticle Measurement

ETH, Hönggerberg, Zurich 9/10 Aug 99

The Sensitivity and Repeatability of Nanoparticle Measurements at High Dilution Ratios.

Chris Barnes

Tel.: +44 (0)1733 582471
 Fax.: +44 (0)1733 582323
 "e" mail cbarn@perkins-engines.com

Product Engineering
 Perkins Engines Co Ltd.
 Peterborough.
 PE1 5NA UK.

Abstract:

This contribution addresses the sensitivity and repeatability of nanoparticle measurements from diesel exhaust. The sampling method is critical in reproducing, as far as is possible, real tailpipe conditions. Currently presented results show marked variation due primarily to sampling method rather than instrumentation. In this case samples are taken from raw exhaust via a system capable of high dilution ratios and rates of dilution similar to that seen from the tailpipe.

The purpose of investigating sensitivity and repeatability is to provide a sound basis for evaluation of changes in particle emissions from base engines, the effect of fuels and additives, and the effect of all forms of aftertreatment.

By fixing certain parameters in the sampling system workable levels of both sensitivity and repeatability were observed over a wide range of engine operating conditions. The results have been translated into a daily system check for the Perkins test bed facility.

Introduction:

The importance of the effect of nanoparticle emissions on air quality and human health is now recognised world wide. Nanoparticle measurement presents a very real technical challenge. Large ambient number concentrations, particularly below 30 nm, have been observed by many researchers. The significant contribution from diesel exhaust is also well documented (1,2). The formation of nanoparticles (as observed close to the tailpipe) is a function of exhaust gas composition (solid, liquid and gas phase), temperature (exhaust and ambient), humidity and dilution rate. The influence of all these parameters has yet to be fully investigated, with the ultimate goal of establishing a reliable and robust engine/vehicle sampling and measurement method that simulates the real atmospheric process.

Perkins has been working in conjunction with The University of Minnesota to help establish a sampling and test protocol. It is recognised that the standard constant volume sampling method for regulated emissions does not necessarily replicate the atmospheric processes and much work still needs to be done (3). However, the process of reducing diesel particle emissions, particularly in the nano range, still needs to be investigated. Perkins has, through the work of The University of Minnesota, installed a sampling and dilution system capable of dilution ratio and temperature control (Figure 6). This system, over a considerable period of operation, has demonstrated a high degree of reproducibility, coupled with good resolution (the system is also described in Ref.3.). These features have now been developed into a test methodology which ensures reliable interpretation of major trends and changes in engine and aftertreatment performance.

The results as presented in Zurich are shown in figures 1-19. It must be stressed that the use of the absolute values is not recommended due to the unique combination of engine and sampling system.

Discussion:

The attached results are encouraging, but still require a high degree of skill and awareness in setting the various parameters. Of particular note are the following:

1. Primary dilution ratio and rate (plus residence time at the primary dilution ratio) have a major influence on the perceived distribution. The engine is known to be both relatively clean and also to behave as a very good polydisperse combustion aerosol generator. The secondary dilution ratio (to give overall dilutions of over 500:1) has a less marked effect.
2. Both the sample temperature and associated residence time in the sample line have a major effect on the particle distribution, but only below 30 nm., the largely carbon based larger particles being sensibly stable. The condition of the dilution air (temperature and humidity) must also be considered in conjunction with the sample condition. The length of sample line seems to be less influential when compared to sample line temperature gradient. The quantity of sample required is small and therefore rapid cooling in small bore pipework is to be expected.
3. The point of sampling for the raw exhaust is less critical (i.e. from just after T/C to some 3m downstream). The temperature drop and residence time in the main exhaust are both relatively minimal.

Conclusions:

Because of the lack of a recognised test method international comparison of results is not reliable, and consequently real performance improvements can only be approximated, particularly in the case of post tailpipe nanoparticle production. Continuing evaluation and investigation of the

THE SENSITIVITY and REPEATABILITY of NANOPARTICLE MEASUREMENTS at HIGH DILUTION RATIOS

By: CHRIS BARNES

Performance, Emissions and Combustion

PERKINS PRODUCT ENGINEERING

3rd NANOPARTICLE WORKSHOP,

ETH, ZURICH, 9/10th Aug 99



© Product Engineering 1999
Proprietary Information-Perkins Engines Co Ltd-h/cbarn/ppt/zurich1.ppt

actual nanoparticle formation process is essential in directing a practical testing standard. Although Perkins has demonstrated that a workable engine test bed system can be developed and operated with a degree of confidence it will continue to investigate and assist in the measurement challenge.

References:

1. Shi J.P. and Harrison R.M. (1998). Particle Size Distribution Emitted from a Modern diesel Engine. Highway and urban Pollution—The Sixth International Symposium Ispra/Varese, Italy.
2. Abdul-Khalek I.S., Kittleson D.B., Graskow B.R., Wei Q. and Brear F. Diesel Exhaust Particle Size: Measurement Issues and Trends. SAE 980525. (Feb 98).
3. Brear F. Particle Measurements from Wall Flow Traps at High Dilution Ratios . 2nd Int. ETH Nanoparticle W/shop, Zurich (1998).

Copyright Perkins Engines Company Ltd. 1999

TEST FORMAT

- **PERKINS STRATEGY:**

- **FIX THE FOLLOWING :**

- HUMIDITY (via dilution air---approx. 15%).
 - DILUTION SYSTEM (Based on Minnesota's development).
 - ENGINE--T4.40 PHASER (a consistent "slave").
 - SAMPLE POINT--ALLOWS FOR AFTERTREATMENT.
 - SAMPLE LINE TEMP.--300 deg C. (Average Exh. Gas temp.)
 - DILUTION RATIO---1000:1 (Based on Minnesota Work to represent atmospheric dilution from a tailpipe) .
 - **THE COMBINATION OF FIXED SAMPLE LINE TEMP. AND FIXED DILUTION EFFECTIVELY FIXES RESIDENCE TIMES.**

ENGINE TEST BED VARIABLES

- **ENGINE:**

- SPEED, LOAD, FUEL (SULPHUR), LUBE OIL, GAS TEMP.

- **SAMPLE:**

- SAMPLE POINT (JUST AFTER T/C THROUGH TO AFTER AFTERTREATMENT).
 - LENGTH OF SAMPLE LINE (RESIDENCE TIME).
 - SAMPLE CONTROL TEMP.
 - DILUTION RATIO (Primary and Secondary).
 - RESIDENCE TIME DURING DILUTION.
 - HUMIDITY OF DILUTION AIR.

PRESENTATION of RESULTS

- PERKINS SAMPLING SYSTEM.
- MINNESOTA SAMPLING SYSTEM.
- ILLUSTRATION of Perkins v. Minnesota Agreement.
- SPREAD of RESULTS @ 1600 rpm/10% load and 2600 rpm/100% load.
- ILLUSTRATION of LOAD DISCRIMINATION @ 1600 rpm.

© Product Engineering 1999
Proprietary Information-Perkins Engines Co Ltd-h/cbarn/ppt/zurich1.ppt




(4)

PERKINS TEST PROCEDURE

- **START of EACH DAY:**
 - RUN 1600 rpm/10% LOAD and 2600 rpm/100% LOAD and COMPARE AGAINST “STANDARD CURVES”.
 - THIS BUILDS UP A BANK OF CONSISTENCY RESULTS AND CONFIRMS OVERALL SYSTEM FUNCTION .
- **BENEFITS:**
 - ALLOWS FUEL EFFECTS TO BE OBSERVED.
 - ALLOWS AFTERTREATMENT TO BE EVALUATED.
 - ALLOWS ENGINE CHANGES TO BE EVALUATED. (and engine types , once the standard curves have been generated).

© Product Engineering 1999
Proprietary Information-Perkins Engines Co Ltd-h/cbarn/ppt/zurich1.ppt





SCHEMATIC OF DILUTION SYSTEM




FIG 6

Product Engineering


Proprietary Information Perkins Engines Company Limited 1999 - All Rights Reserved.
 COMB381 BUSDEVICOMACRUMBERREC.LIB



6

7

**REPEATABILITY EXERCISE-- 1600 RPM. 1000:1 DILUTION RATIO.
18 data sets over 2 months- 10% LOAD, 300 degC Sample line**



P/kgall/combust/wip/P3811/ RPT16b.xls

C.Barnes 2 Aug 99


Bed 65 -SMPS Results-REPEATABILITY

8

F149

8

**Comparison between Perkins Two Stage Dilution at-1600rpm, 50% Load at 1000:1 Dil.,
300 degC sample temp. , and a recent result from Minnesota on the same engine type
, and with their sampling and two stage dilution system (Dilution ratio unknown).**



C. Barnes 03 Aug 99


Bed 65 SMPS Results-MAP

P/kgall/combust/wip/P3811/minn1.xls

8

F148

ENGINE MAP- LOAD EFFECT @1600rpm, 100%,-10% load at 1000:1 Dil., 300 degC sample temp




C. Barnes 03 Aug99

Bed 65 SMPS Results-MAP

P/kgall/combust/wip/P3811/map09a.xls

REPEATABILITY EXERCISE-- 2600 RPM. 1000:1 DILUTION RATIO. 18 Data sets over 2 months--100% LOAD, 300 degC Sample line



C. Barnes 2 Aug 99

Bed 65 SMPS Results-REPEATABILITY

P/kgall/combust/wip/P3811/RPT26b.xls


F1611

(1)

(10)

F1610

**REPEATABILITY-Mean of 18/24 sets at 2600/1600 rpm, 100%/10% Load respectively:
1000:1 Dil., 300 degC**



C.Barnes 03 Aug 99


Bed 65 SMPS Results-REPEATABILITY

P/kgall/combust/wip/ P3811/RPTava.xls

PRESENTATION of RESULTS

- **MEAN and Std DEV. @ 1600/10% and 2600/100% points.**
- **ILLUSTRATION of HEATED SAMPLE LINE TEMP. EFFECTS @ 1600 rpm/10% load-- Maximum Suppression of losses due to Warming Effect on sample from 94 deg C to 119 deg C. with line at 300 deg. C ?**

REPEATABILITY-Mean of 18 sets at 2600 rpm, 100% Load, 1000:1 Dil.,300 degC over 3 months-Std 450 ppm sulphur fuel




C.Barnes 2 Aug 99

Bed 65 SMPS Results-REPEATABILITY

P/kgall/combust/wip/ P3811/RPT26b.xls

REPEATABILITY EXERCISE--Mean of 24 data sets at 1600 rpm,10% load,1000:1 Dil.,300 degC over 3 Months-Std 450 ppm Sulphur Fuel



C.Barnes 2 Aug 99

Bed 65 Results-SMPS-REPEATABILITY-

P/kgall/Combust/WIP/P3811/RPT16b.xls

FIG 15

FIG 14

PRESENTATION of RESULTS

- **HEATED LINE EFFECTS @ 2600 rpm/100% Load--Slightly increased losses with Reducing Temp. from a sample at 390 deg. C?**
- **ILLUSTRATION of Heated line EXTENSION effects-nano-particle growth suppression at 1600/10%, and possible growth @ 2600/100% ?**

© Product Engineering 1999
 Proprietary Information-Perkins Engines Co Ltd-h/cbarn/ppt/zurich1.ppt



FIG 17

T4.40 AEU644208Y-4 Cyl on Highway-81 kW @ 2600 rpm PERKINS Product Engineering JOB3811 Source 17057/Ht1610a.xls

Effect of SAMPLE LINE TEMP. 1600 RPM. 500:1 DILUTION RATIO. 10% LOAD





FIG 16




C.Barnes 03 Aug 99

Bed 65 SMPS Results-REPEATABILITY

P/kgall/combust/wip/ P3811/heatext1a.xls

FIG 19

**Effect of SAMPLE LINE TEMP. 2600 RPM. 500:1 DILUTION RATIO.
100% LOAD**



C.Barnes 03 Aug 99

Bed 65 SMPS Results

P/kgall/combust/wip/P3811/26100a.xls

FIG 18