

Real time measurement of the effective density and fractal dimension of diesel exhaust particles

Jorma Keskinen, Annele Virtanen, Jyrki Ristimäki,

Tampere University of Technology

Institute of Physics

Aerosol Physics Laboratory

Tampere

Finland

Contents

- **Motivation**
- **Description of method**
- **Laboratory test**
- **Diesel exhaust measurement**
- **Discussion**



Motivation

- **Density and fractal dimension carry information:**
 - particle properties
 - origin of particles
 - structure of particles
- **Existing methods for density measurement**
 - DMA and Impactor in series (Kelly and McMurry, 1992)
 - DMA and APM in series (McMurry et al., 2002)
 - Accurate but slow (single mobility size at a time)
- **SMPS and ELPI used in several engine labs**
 - Parallel data in abundance



Effective density

- **SMPS**: distribution as a function of mobility diameter
- **ELPI**: classification according to aerodynamic diameter
- **Mobility and aerodynamic diameter linked through effective density:**

$$d_a^2 C_c(d_a) \rho_0 = d_b^2 C_c(d_b) \frac{[C_c(d_m)]^3 \rho_p}{[C_c(d_b)]^3 \chi^3} = d_b^2 C_c(d_b) \rho_e$$




Description of the method


- **Simultaneous measurement with SMPS and ELPI**
- **Number distribution measured by SMPS is converted to ELPI "current distribution"**
- **Calculated and measured ELPI current distributions compared**
 - Cost = difference between simulated and measured currents
- **Cost minimization**
 - => Repeated with varying density until minimum difference between simulated and measured currents



Description of the method



Description of the method




Constant density test particles

- **Liquid particles:**
 - density 0,912 (DOS) - 1,9 g/cm³ (Fomblin)
- **Solid particles:**
 - density 2,17 (NaCl) - 10,49 g/cm³ (Ag)
- **Size range 40-280nm (peak diameter)**



Constant density test results




Constant density results

ρ (fitted)	DOS	Santovac	Fomblin	NaCl	Zn	Ag
Number of scans	22	5	7	4	3	3
Standard dev.	0.05	0.07	0.09	0.10 / 0.06	0.01	0.93 / 0.86
Standard dev. %	5.4 %	6.0 %	4.5 %	3.97 / 2.28	0.2 %	7.74 / 8.14
min	0.72	1.06	1.71	2.42 / 2.42	7.39	11.33 / 9.81
max	0.90	1.23	1.84	2.67 / 2.54	7.42	13.09 / 11.51
Average	0.85	1.11	1.91	2.57 / 2.48	7.40	12.04 / 10.58
Bulk value	0.912	1.2	1.9	2.17	7.14	10.49
error %	-6.5 %	-7.2 %	0.4 %	18.2 / 14.5	3.7 %	14.7 / 0.9




Diesel soot: fractal like agglomerates


- Fractal dimension d_f defines the scaling of ρ_e and d_b :



$$\rho_e \propto d_b^{d_{fm}-3}$$




Agglomerates: density vs d_b



Agglomerates: silver particles

- reference method: DMA (monodisperse particles) + impactor




Diesel vehicle tests

- **Audi A4 1.9 TDI (Euro II)**
 - Direct injection
 - EGR + oxidation catalyst
- **Euro II fuel (EN590)**
- **Steady state tests on chassis dyno**
- **Dilution methods**
 - Porous tube diluter (+ thermo denuder)
 - 2 stage ejector diluter: 1st at 180°C, 2nd at room temperature



Example results



Discussion 1: soot particles

- **Effective density: 0.4 – 1.3 g/cm³ (soot)**
 - Comparable to other methods.
- **Fractal dimension: 2.6-3**
 - Higher than most other studies
 - We obtain average over the size distribution
 - Higher d_f for small particles (monomer-cluster agglomeration)
 - Lower d_f for larger particles (cluster-cluster)



Discussion 2: method

- **Positive**
 - Simple, no time loss from distribution measurement
 - Fast enough for on-line operation
 - Old data can be re-evaluated
- **Negative**
 - Less accurate than serial methods
 - Inaccuracy increases for low fractal dimension values
- **Further development**
 - Search method development
 - Multi-mode distributions

Presentation based on:

Ristimäki J., Virtanen A., Marjamäki M., Rostedt A., Keskinen J. (2002) *J. Aerosol Sci.* **33**, 1541

Virtanen, A., Ristimäki, J., Marjamäki, M., Vaaraslahti, K., Keskinen, J., and Lappi, M. (2002) Effective density of diesel exhaust particles as a function of size. *SAE 2002-01-0056*.

Virtanen, A., Ristimäki J., Keskinen, J. (2003) Method for measuring effective density and fractal dimension of aerosol agglomerates. Submitted to *AST*.

